



Goatskin Leather Protector Driver Glove

MINIMUM DISTANCE FROM PROTECTOR TO RUBBER GLOVE

GLOVE CLASS	LEATHER PROTECTOR CUFF LINE
00, 0	1/2 inch from cuff
1	1 inch from cuff
2	2 inches from cuff
3	3 inches from cuff
4	4 inches from cuff

- Class 00 and Class 0 rubber voltage gloves should be worn with 10" leather glove protectors
- Top grain goatskin leather
- 10" long
- Keystone thumb
- Shirred elastic back
- Color coded overcast for easy size identification
- Available in sizes 7-11

800-MALLORY • mallory.com